

Guidelines For The Care, Use & Storage Of Digital Thermometers.

Instrument Care

Digital thermometers and their probes need careful handling at all times to ensure a long life and to prevent probe damage.

DO'S

- ✓ Care should be taken when disconnecting the probe from the instrument.
(Only applicable if probe is removable)
- ✓ Always clean your thermometer and probe after use
- ✓ Always store your thermometer and probe *dry* and in a dry, safe place.
- ✓ In the interests of hygiene, clean the probe before and after each use.
- ✓ Always use the correct probe for the type of measurement being taken.



DONT'S

- ◆ Never drop the instrument or lift the instrument by the lead or probe.
- ◆ Never submerge the instrument and probe in water or other liquids/solutions.
- ◆ Do not disconnect the probe from the instrument by pulling the cable.
(Only applicable if probe is removable)
- ◆ Do not wrap the cable around the instrument.



Sterilisation and Cleansing of Probes & Storage Unit

Before and after each use, always clean and sterilise the probe by using an anti-bacterial wipe.

This reduces the risk of passing bacteria from one food to another - eliminating the risk of cross-contamination.

IMPORTANT : The box / pouch the thermometer is stored in must be kept clean at all times, to avoid cross contamination

Return Address For Calibration :

Rototherm Ltd,
Unit C2,
Clonlara Avenue,
Baldonnell Business Park,
Naas Road,
Dublin 22.